

```
In [3]: import numpy as np
import matplotlib.pyplot as plt
import os
```

```
In [5]:
        def peak_detection(t, sig, thresh):
            peaks = []
            max_val = -np.Inf
            N = len(sig)
            for i in range(0, N):
                 if sig[i] > max val :
                     max_val = sig[i]
                     position = t[i]
            peaks.append((position, max_val))
            return np.array(peaks)
        os.chdir('C:/Users/chris/PycharmProjects/lab1')
        csv filename = 'sample sensor data.csv'
        data = np.genfromtxt(csv_filename, delimiter=',').T
        timestamps = (data[0] - data[0,0]) / 1000
        accel data = data[1:4]
        gyro_data = data[4:-1]
        max_peaks = peak_detection(timestamps, accel_data[0], 3)
        plt.plot(timestamps, accel_data[0])
        plt.title("First axis of accelerometer data")
        plt.xlabel("Time")
        plt.ylabel("Meters per second")
        plt.scatter(max peaks[:, 0], max peaks[:, 1], color='red')
        plt.show()
```



```
In [2]: def peak_detection(t, sig, thresh):
            peaks = []
            max val = -np.Inf
            prev value = -np.Inf
            N = len(sig)
            for i in range(0, N-1):
                 next_value = sig[i+1]
                 if sig[i] > max_val and sig[i] > thresh:
                     max_val = sig[i]
                     position = t[i]
                 if sig[i] < 0 and max_val != -np.Inf :</pre>
                     peaks.append((position, max_val))
                     max val = -np.Inf
            return np.array(peaks)
        os.chdir('C:/Users/chris/PycharmProjects/lab1')
        csv_filename = 'sample_sensor_data.csv'
        data = np.genfromtxt(csv_filename, delimiter=',').T
        timestamps = (data[0] - data[0,0]) / 1000
        accel_data = data[1:4]
        gyro data = data[4:-1]
        max_peaks = peak_detection(timestamps, accel_data[0], 3)
        plt.plot(timestamps, accel data[0])
        plt.title("First axis of accelerometer data")
        plt.xlabel("Time")
        plt.ylabel("Meters per second")
        plt.scatter(max_peaks[:, 0], max_peaks[:, 1], color='red')
        plt.show()
```



In []: